

Liste des véhicules compatibles

<u>Fabia I (1999 à 2008)</u>	<u>Fabia II (2007 à 2010)</u>	<u>Felicia (1995 à 1999)</u>
<u>Octavia I (1U) (1996 à 2008)</u>	<u>Octavia II (1Z) (2004 à 2009)</u>	<u>Octavia II FL (1Z) (2009 à 2010)</u>
<u>Praktik (2006 à 2010)</u>	<u>Roomster (2006 à 2010)</u>	<u>Superb I (3U) (2002 à 2008)</u>
<u>Superb II (3T) (2009 à 2013)</u>	<u>Yeti (2010)</u>	

Modèle	Type calculateur	Nom
Fabia I	Autoradio	Radio - Diagnose (KW 1281)
Fabia I	ABS	Bosch 5.7 - ABS (KW 1281)
Fabia I	ABS	Bosch 8.0 - ABS (KWP2000)
Fabia I	ABS	Bosch 8.0 - ABS/EDL/ASR (KWP2000)
Fabia I	CPasserelle centrale	K -> CAN (KW 1281)
Fabia I	Climatisation	Climatic (KW 1281)
Fabia I	Système de confort	Système de confort (alarm) [KW 1281]
Fabia I	Système de confort	Système de confort (no alarm) [KW 1281]
Fabia I	Electrical Center	Central electronics (KW 1281)
Fabia I	Calculateur diesel	AMF 1.4 General
Fabia I	Calculateur diesel	ASY 1.9 SDI (KW 1281)
Fabia I	Calculateur diesel	ASZ 1.9 General
Fabia I	Calculateur diesel	ATD 1.9 General
Fabia I	Calculateur diesel	AXR 1.9 General
Fabia I	Calculateur diesel	BLT 1.9 General
Fabia I	Calculateur diesel	BNM 1.4 General
Fabia I	Calculateur diesel	BNV 1.4 General
Fabia I	Calculateur essence	AME 1.4 General
Fabia I	Calculateur essence	AQV 1.0 General
Fabia I	Calculateur essence	AQW 1.4 Simos 3 PA (KW 1281)
Fabia I	Calculateur essence	ARV 1.0 General
Fabia I	Calculateur essence	AUA 1.4 General
Fabia I	Calculateur essence	AUB 1.4 General

Fabia I	Calculateur essence	AWY 1.2 General
Fabia I	Calculateur essence	AZE 1.4 General
Fabia I	Calculateur essence	AZF 1.4 General
Fabia I	Calculateur essence	AZL 2.0 General
Fabia I	Calculateur essence	AZQ 1.2 Simos 3 PE (KW 1281)
Fabia I	Calculateur essence	BBY 1.4 General
Fabia I	Calculateur essence	BBZ 1.4 General
Fabia I	Calculateur essence	BKY 1.4 Marelli (KW 1281)
Fabia I	Calculateur essence	BMD 1.2 General
Fabia I	Calculateur essence	BME 1.2 Simos (KW 1281)
Fabia I	Calculateur essence	BUD 1.4 General
Fabia I	Boite de vitesse automatique	Diagnose (KW 1281)
Fabia I	Xénon	Xénon aim control - Diagnose (KWP 1281)
Fabia I	Antivol	Immo/Instr (KW 1281)
Fabia I	Antivol	Antivol (KW 1281)
Fabia I	Instrument / Dashboard	Instrument (KW 1281)
Fabia I	Other	Navigation - Diagnose (KW 1281)
Fabia I	Parking System	Parking assistance (KW 1281)
Fabia I	Airbag	Airbag (KW 1281)
Fabia I	Direction assistée	Direction assistée assistance (KW 1281)
Fabia II	Autoradio	Radio - Diagnose (KWP2000)
Fabia II	ABS	Bosch 8.0 - ABS (KWP2000)
Fabia II	ABS	Bosch 8.0 - ABS/ESP (KWP2000)
Fabia II	Passerelle centrale	K -> CAN (KW 1281)
Fabia II	Climatisation	Climatronic (KWP2000)
Fabia II	Climatisation	Diagnose (KW 1281)

Fabia II	Système de confort	Système de confort (KW 1281)
Fabia II	Centrale électrique	Central electronics (KW 1281)
Fabia II	Calculateur diesel	BJS 1.9 General
Fabia II	Calculateur diesel	BLS 1.9 General
Fabia II	Calculateur diesel	BMS 1.4 TDI-PD (KWP2000)
Fabia II	Calculateur diesel	BNM 1.4 General
Fabia II	Calculateur diesel	BNV 1.4 General
Fabia II	Calculateur diesel	BSW 1.9 General
Fabia II	Calculateur essence	BBM 1.2 General
Fabia II	Calculateur essence	BTS 1.6 General
Fabia II	Calculateur essence	BXW 1.4 4LV (KWP2000)
Fabia II	Calculateur essence	BZG 1.2 Simos (KWP2000)
Fabia II	Calculateur essence	CEV 1.2 Simos (KWP2000)
Fabia II	Calculateur essence	CGPA 1.2 Simos (KWP2000)
Fabia II	Calculateur essence	CHFA 1.2 Simos (KWP2000)
Fabia II	Calculateur essence	CHTA 1.2 Simos (KWP2000)
Fabia II	Xénon	Xénon aim control (KWP2000)
Fabia II	Antivol	Antivol (KW 1281)
Fabia II	Instrumentation	Instrument (KW 1281)
Fabia II	Radar de recul	Parking assistance (KWP2000)
Fabia II	Airbag	Airbag (KW 1281)
Fabia II	Direction assistée	Direction assistée assistance (KW 1281)
Felicia	ABS	ABS - Diagnose (KW 1281)
Felicia	Climatisation	Diagnose (KW 1281)
Felicia	Calculateur essence	135B 1.3 Mono-Motronic - Diagnose (KW 1281)
Felicia	Calculateur essence	135M 1.3 Simos 2P (KW 1281)

Felicia	Calculateur essence	136B 1.3 Mono-Motronic - Diagnose (KW 1281)
Felicia	Calculateur essence	AEE 1.6 IAW 1AV (KW 1281)
Felicia	Calculateur essence	AMG 1.3 General
Felicia	Calculateur essence	AMH 1.3 General
Felicia	Unité de controle de pompe carburant	Diesel pump (AEF 1.9) [KW 1281]
Felicia	Boite de vitesse automatique	Diagnose (KW 1281)
Felicia	Antivol	Antivol (KW 1281)
Felicia	Airbag	Airbag (KW 1281)
Octavia I (1U)	Autoradio	Radio - Diagnose (KW 1281)
Octavia I (1U)	ABS	ABS Mark 20 IE (KW 1281)
Octavia I (1U)	ABS	ABS Mark 60 (KWP2000)
Octavia I (1U)	ABS	ABS/EDL Mark 20 IE (KW 1281)
Octavia I (1U)	ABS	ABS/EDL/ASR Mark 20 IE (KW 1281)
Octavia I (1U)	ABS	ABS/EDL/ASR Mark 60 (KWP2000)
Octavia I (1U)	ABS	ABS/EDL/ASR/ESP Mark 60 (KWP2000)
Octavia I (1U)	Passerelle centrale	K -> CAN (KW 1281)
Octavia I (1U)	Centrale de verrouillage	Generation 1 (->1997/09) Centrale de verrouillage - Diagnose (KW 1281)
Octavia I (1U)	Centrale de verrouillage	Generation 2 (1997/10->1998/07) Centrale de verrouillage - Diagnose (KW 1281)
Octavia I (1U)	Centrale de verrouillage	Generation 2.5 (1998/08->2001/04) Centrale de verrouillage [KW 1281]
Octavia I (1U)	Centrale de verrouillage	Generation 3 (2001/05->) Centrale de verrouillage - Diagnose (KW 1281)
Octavia I (1U)	Climatisation	Diagnose (KW 1281)

Octavia I (1U)	Système de confort	Système de confort - Generation 1 (->1997/09) [KW 1281]
Octavia I (1U)	Système de confort	Système de confort - Generation 2 (1997/10->1998/07) [KW 1281]
Octavia I (1U)	Système de confort	Système de confort - Generation 2.5 (1998/08->2001/04) [KW 1281]
Octavia I (1U)	Système de confort	Système de confort - Generation 3 (2001/05->) [KW 1281]
Octavia I (1U)	Centrale électrique	Central electronics - Diagnose (KW 1281)
Octavia I (1U)	Calculateur diesel	AGP 1.9 SDI (KW 1281)
Octavia I (1U)	Calculateur diesel	AGR 1.9 TDI (->2000/07) [KW 1281]
Octavia I (1U)	Calculateur diesel	AGR 1.9 TDI (2000/08->) [KW 1281]
Octavia I (1U)	Calculateur diesel	AHF 1.9 TDI (->2000/07) [KW 1281]
Octavia I (1U)	Calculateur diesel	AHF 1.9 TDI (2000/08->) [KW 1281]
Octavia I (1U)	Calculateur diesel	ALH 1.9 General
Octavia I (1U)	Calculateur diesel	AQM 1.9 General
Octavia I (1U)	Calculateur diesel	ASV 1.9 TDI (KW 1281)
Octavia I (1U)	Calculateur diesel	ASZ 1.9 General
Octavia I (1U)	Calculateur diesel	ATD 1.9 General
Octavia I (1U)	Calculateur diesel	AXR 1.9 TDI (KW 1281)
Octavia I (1U)	Calculateur essence	AEE 1.6 IAW 1AV (KW 1281)
Octavia I (1U)	Calculateur essence	AEG 2.0 General
Octavia I (1U)	Calculateur essence	AEH 1.6 Simos (KW 1281)
Octavia I (1U)	Calculateur essence	AGN 1.8 General
Octavia I (1U)	Calculateur essence	AGU 1.8 General
Octavia I (1U)	Calculateur essence	AKL 1.6 Simos (KW 1281)

Octavia I (1U)	Calculateur essence	AMD 1.4 General
Octavia I (1U)	Calculateur essence	APK 2.0 General
Octavia I (1U)	Calculateur essence	AQY 2.0 General
Octavia I (1U)	Calculateur essence	ARX 1.8 General
Octavia I (1U)	Calculateur essence	ARZ 1.8 General
Octavia I (1U)	Calculateur essence	AUM 1.8 General
Octavia I (1U)	Calculateur essence	AUQ 1.8 Motronic (KW 1281)
Octavia I (1U)	Calculateur essence	AVU 1.6 General
Octavia I (1U)	Calculateur essence	AXP 1.4 Motronic (KW 1281)
Octavia I (1U)	Calculateur essence	AZH 2.0 General
Octavia I (1U)	Calculateur essence	AZJ 2.0 General
Octavia I (1U)	Calculateur essence	BCA 1.4 General
Octavia I (1U)	Calculateur essence	BFQ 1.6 Simos (KW 1281)
Octavia I (1U)	Boite de vitesse automatique	01M (KW 1281)
Octavia I (1U)	Xénon	Left light (master) [KW 1281]
Octavia I (1U)	Xénon	Right light (slave) [KW 1281]
Octavia I (1U)	Antivol	Immo III (KW 1281)
Octavia I (1U)	Antivol	Immo/Instr [KW 1281]
Octavia I (1U)	Instrumentation	Instrument (KW 1281)
Octavia I (1U)	Instrumentation	QG0 - Instrument (KW 1281)
Octavia I (1U)	Instrumentation	QG1, QG2 - Longlife Diesel (KW 1281)
Octavia I (1U)	Instrumentation	QG1, QG2 - Longlife Gasoline (KW1281)
Octavia I (1U)	Autre	4WD electronics - Diagnose (KW 1281)
Octavia I (1U)	Autre	Navigation - Diagnose (KW 1281)
Octavia I (1U)	Autre	Seat module, driver - Diagnose (KW 1281)

Octavia I (1U)	Radar de recul	Parking assistance (KW 1281)
Octavia I (1U)	Airbag	Airbag (KW 1281)
Octavia I (1U)	Direction assistée	Direction assistée assistance - Diagnose (KW 1281)
Octavia I (1U)	Direction assistée	Direction assistée wheel electronics - Diagnose (KW 1281)
Octavia II (1Z)	Chauffage additionnel	Electrical powered heater (CAN TP20)
Octavia II (1Z)	Chauffage additionnel	Fuel powered heater - Diagnose (CAN TP20)
Octavia II (1Z)	Autoradio	Radio - Diagnose (CAN TP20)
Octavia II (1Z)	ABS	Mark 60 - ABS/ESP (1K0907379AC) [CAN TP20]
Octavia II (1Z)	ABS	Mark 60 - ABS/ESP (1K0907379K) [CAN TP20]
Octavia II (1Z)	ABS	Mark 70 - ABS (CAN TP20)
Octavia II (1Z)	Passerelle centrale	Gateway (CAN TP20)
Octavia II (1Z)	Climatisation	Climatic (CAN TP20)
Octavia II (1Z)	Climatisation	Climatronic (CAN TP20)
Octavia II (1Z)	Système de confort	Système de confort (CAN TP20)
Octavia II (1Z)	Porte	Driver door (CAN TP20)
Octavia II (1Z)	Porte	Passenger door (CAN TP20)
Octavia II (1Z)	Porte	Rear left door (CAN TP20)
Octavia II (1Z)	Porte	Rear right door (CAN TP20)
Octavia II (1Z)	Centrale électrique	Central electronics (CAN TP20)
Octavia II (1Z)	Calculateur diesel	AZV 2.0 General
Octavia II (1Z)	Calculateur diesel	BJB 1.9 General
Octavia II (1Z)	Calculateur diesel	BKC 1.9 General

Octavia II (1Z)	Calculateur diesel	BKD 2.0 TDI (CAN TP20)
Octavia II (1Z)	Calculateur diesel	BLS 2.0 TDI (CAN TP20)
Octavia II (1Z)	Calculateur diesel	BMM 2.0 TDI (CAN TP20)
Octavia II (1Z)	Calculateur diesel	BMN 2.0 General
Octavia II (1Z)	Calculateur diesel	BXE 1.9 TDI (CAN TP20)
Octavia II (1Z)	Calculateur diesel	CEGA 2.0 TDI-CR (CAN TP20)
Octavia II (1Z)	Calculateur essence	AXX 2.0 Motronic (CAN TP20)
Octavia II (1Z)	Calculateur essence	BCA 1.4 General
Octavia II (1Z)	Calculateur essence	BGU 1.6 Simos (CAN TP20)
Octavia II (1Z)	Calculateur essence	BLF 1.6 Motronic (CAN TP20)
Octavia II (1Z)	Calculateur essence	BLR 2.0 General
Octavia II (1Z)	Calculateur essence	BLX 2.0 General
Octavia II (1Z)	Calculateur essence	BLY 2.0 General
Octavia II (1Z)	Calculateur essence	BSE 1.6 Simos (CAN TP20)
Octavia II (1Z)	Calculateur essence	BSF 1.6 General
Octavia II (1Z)	Calculateur essence	BUD 1.4 General
Octavia II (1Z)	Calculateur essence	BVX 2.0 General
Octavia II (1Z)	Calculateur essence	BVY 2.0 General
Octavia II (1Z)	Calculateur essence	BVZ 2.0 General
Octavia II (1Z)	Calculateur essence	BWA 2.0 Motronic (CAN TP20)
Octavia II (1Z)	Calculateur essence	BZB 1.8 TFSI (CAN TP20)
Octavia II (1Z)	Calculateur essence	CCSA 1.6 Simos (CAN TP20)
Octavia II (1Z)	Boite de vitesse automatique	02E (DSG) [CAN TP20]
Octavia II (1Z)	Boite de vitesse automatique	Diagnose (CAN TP20)
Octavia II (1Z)	Xénon	Xénon aim control (CAN TP20)
Octavia II (1Z)	Antivol	Antivol (CAN TP20)
Octavia II (1Z)	Instrumentation	Diagnose (CAN UDS/CAN TP20)

Octavia II (1Z)	Instrumentation	Instrument (CAN TP20)
Octavia II (1Z)	Autre	Nawigacja - Diagnose (CAN TP20)
Octavia II (1Z)	Radar de recul	Parking assistance (CAN TP20)
Octavia II (1Z)	Airbag	Airbag (CAN TP20)
Octavia II (1Z)	Direction assistée	Direction assistée assistance (CAN TP20)
Octavia II (1Z)	Direction assistée	Direction assistée wheel electronics (CAN TP20)
Octavia II (1Z)	Attelage	Trailer module - Diagnose (CAN TP20)
Octavia II FL (1Z)	Chauffage additionnel	Fuel powered heater - Diagnose (CAN TP20)
Octavia II FL (1Z)	Autoradio	Radio - Diagnose (CAN TP20)
Octavia II FL (1Z)	ABS	Mark 60 EC - ABS/ESP (CAN TP20)
Octavia II FL (1Z)	ABS	Mark 70 - ABS (CAN TP20)
Octavia II FL (1Z)	Passerelle centrale	Gateway (CAN TP20)
Octavia II FL (1Z)	Climatisation	Climatic (CAN UDS)
Octavia II FL (1Z)	Climatisation	Climatronic (CAN UDS)
Octavia II FL (1Z)	Porte	Driver door - Diagnose (CAN TP20)
Octavia II FL (1Z)	Porte	Passenger door - Diagnose (CAN TP20)
Octavia II FL (1Z)	Porte	Rear left door - Diagnose (CAN TP20)
Octavia II FL (1Z)	Porte	Rear right door - Diagnose (CAN TP20)
Octavia II FL (1Z)	Centrale électrique	Central electronics (CAN TP20)
Octavia II FL (1Z)	Calculateur diesel	AZV 2.0 General
Octavia II FL (1Z)	Calculateur diesel	BJB 1.9 General
Octavia II FL (1Z)	Calculateur diesel	BJS 2.0 General
Octavia II FL (1Z)	Calculateur diesel	BKC 1.9 General
Octavia II FL (1Z)	Calculateur diesel	BKD 2.0 TDI (CAN TP20)

Octavia II FL (1Z)	Calculateur diesel	BLS 2.0 General
Octavia II FL (1Z)	Calculateur diesel	BMM 2.0 TDI (CAN TP20)
Octavia II FL (1Z)	Calculateur diesel	BMN 2.0 General
Octavia II FL (1Z)	Calculateur diesel	BXE 1.9 TDI (CAN TP20)
Octavia II FL (1Z)	Calculateur diesel	CAYC 1.6 TDI-CR (CAN UDS)
Octavia II FL (1Z)	Calculateur diesel	CEGA 2.0 TDI-CR (CAN TP20)
Octavia II FL (1Z)	Calculateur diesel	CLCB 2.0 General
Octavia II FL (1Z)	Calculateur essence	BCA 1.4 General
Octavia II FL (1Z)	Calculateur essence	BLF 1.6 Motronic (CAN TP20)
Octavia II FL (1Z)	Calculateur essence	BLR 2.0 General
Octavia II FL (1Z)	Calculateur essence	BLX 2.0 General
Octavia II FL (1Z)	Calculateur essence	BLY 2.0 General
Octavia II FL (1Z)	Calculateur essence	BSE 1.6 Simos (CAN TP20)
Octavia II FL (1Z)	Calculateur essence	BSF 1.6 General
Octavia II FL (1Z)	Calculateur essence	BUD 1.4 General
Octavia II FL (1Z)	Calculateur essence	BVX 2.0 General
Octavia II FL (1Z)	Calculateur essence	BVY 2.0 General
Octavia II FL (1Z)	Calculateur essence	BVZ 2.0 General
Octavia II FL (1Z)	Calculateur essence	BWA 2.0 Motronic (CAN TP20)
Octavia II FL (1Z)	Calculateur essence	BZB 1.8 TFSI (CAN TP20)
Octavia II FL (1Z)	Calculateur essence	CAXA 1.4 TFSI (CAN TP20)
Octavia II FL (1Z)	Calculateur essence	CBZB 1.2 TFSI (CAN UDS)
Octavia II FL (1Z)	Calculateur essence	CCSA 1.6 Simos (CAN TP20)
Octavia II FL (1Z)	Calculateur essence	CCZA 2.0 General
Octavia II FL (1Z)	Calculateur essence	CDAA 1.8 TFSI (CAN TP20)
Octavia II FL (1Z)	Calculateur essence	CDAB 1.8 TFSI (CAN TP20)
Octavia II FL (1Z)	Calculateur essence	CHGA 1.6 General

Octavia II FL (1Z)	Boite de vitesse automatique	02E (DSG) [CAN TP20]
Octavia II FL (1Z)	Boite de vitesse automatique	Diagnose (CAN TP20)
Octavia II FL (1Z)	Xénon	Xénon aim control (CAN TP20)
Octavia II FL (1Z)	Antivol	Antivol (CAN UDS)
Octavia II FL (1Z)	Instrumentation	Diagnose (CAN UDS/CAN TP20)
Octavia II FL (1Z)	Autre	Navigation - Diagnose (CAN TP20/CAN UDS)
Octavia II FL (1Z)	Radar de recul	Parking assistance (4-channel) [CAN TP20]
Octavia II FL (1Z)	Airbag	Airbag (CAN TP20)
Octavia II FL (1Z)	Direction assistée	Direction assistée assistance (CAN TP20)
Octavia II FL (1Z)	Direction assistée	Direction assistée wheel electronics (CAN TP20)
Octavia II FL (1Z)	Attelage	Trailer module - Diagnose (CAN TP20)
Praktik	Autoradio	Radio - Diagnose (KWP2000)
Praktik	ABS	Bosch 8.0 - ABS (KWP2000)
Praktik	ABS	Bosch 8.0 - ABS/ASR (KWP2000)
Praktik	ABS	Bosch 8.0 - ABS/ESP (KWP2000)
Praktik	Passerelle centrale	K -> CAN (KW 1281)
Praktik	Climatisation	Climatic (KW 1281)
Praktik	Climatisation	Climatronic (KWP2000)
Praktik	Système de confort	Système de confort (KW 1281)
Praktik	Centrale électrique	Central electronics (KW 1281)
Praktik	Calculateur diesel	AXR 1.9 General
Praktik	Calculateur diesel	BJS 1.9 General
Praktik	Calculateur diesel	BLS 1.9 General

Praktik	Calculeur diesel	BMS 1.4 TDI-PD (KWP2000)
Praktik	Calculeur diesel	BNM 1.4 TDI-PD (KW 1281)
Praktik	Calculeur diesel	BNV 1.4 General
Praktik	Calculeur diesel	BSW 1.9 General
Praktik	Calculeur essence	BME 1.2 General
Praktik	Calculeur essence	BTS 1.6 Motronic (KWP2000)
Praktik	Calculeur essence	BUD 1.4 General
Praktik	Calculeur essence	BXW 1.4 General
Praktik	Calculeur essence	BZG 1.2 Simos (KWP2000)
Praktik	Calculeur essence	CEV 1.2 Simos (KWP2000)
Praktik	Calculeur essence	CGPA 1.2 Simos (KWP2000)
Praktik	Calculeur essence	CHTA 1.2 Simos (KWP2000)
Praktik	Xénon	Xénon aim control (KWP2000)
Praktik	Antivol	Antivol (KW 1281)
Praktik	Instrumentation	Instrument (KW 1281)
Praktik	Radar de recul	Parking assistance (KWP2000)
Praktik	Airbag	Airbag (KW 1281)
Praktik	Direction assistée	Direction assistée assistance - Diagnose (KW 1281)
Roomster	Autoradio	Radio - Diagnose (KWP2000)
Roomster	ABS	Bosch 8.0 - ABS (KWP2000)
Roomster	ABS	Bosch 8.0 - ABS/ASR (KWP2000)
Roomster	ABS	Bosch 8.0 - ABS/ESP (KWP2000)
Roomster	Passerelle centrale	K -> CAN (KW 1281)
Roomster	Climatisation	Climatic (KW 1281)
Roomster	Climatisation	Climatronic (KWP2000)
Roomster	Système de confort	Système de confort (KW 1281)

Roomster	Centrale électrique	Central electronics (KW 1281)
Roomster	Calculateur diesel	AXR 1.9 General
Roomster	Calculateur diesel	BJS 1.9 General
Roomster	Calculateur diesel	BLS 1.9 General
Roomster	Calculateur diesel	BMS 1.4 TDI-PD (KWP2000)
Roomster	Calculateur diesel	BNM 1.4 TDI-PD (KW 1281)
Roomster	Calculateur diesel	BNV 1.4 General
Roomster	Calculateur diesel	BSW 1.9 General
Roomster	Calculateur essence	BME 1.2 General
Roomster	Calculateur essence	BTS 1.6 Motronic (KWP2000)
Roomster	Calculateur essence	BUD 1.4 General
Roomster	Calculateur essence	BXW 1.4 General
Roomster	Calculateur essence	BZG 1.2 Simos (KWP2000)
Roomster	Calculateur essence	CEV 1.2 Simos (KWP2000)
Roomster	Calculateur essence	CGPA 1.2 Simos (KWP2000)
Roomster	Calculateur essence	CHTA 1.2 Simos (KWP2000)
Roomster	Xénon	Xénon aim control (KWP2000)
Roomster	Antivol	Antivol (KW 1281)
Roomster	Instrumentation	Instrument (KW 1281)
Roomster	Radar de recul	Parking assistance (KWP2000)
Roomster	Airbag	Airbag (KW 1281)
Roomster	Direction assistée	Direction assistée assistance - Diagnose (KW 1281)
Superb I (3U)	Autoradio	Radio - Diagnose (KW 1281)
Superb I (3U)	ABS	Bosch 5.3 - ABS/EDL (KW 1281)
Superb I (3U)	ABS	Bosch 5.3 - ABS/EDL/ASR (KW 1281)
Superb I (3U)	ABS	Bosch 5.7 - ABS/ESP (KW 1281)

Superb I (3U)	CPasserelle centrale	K -> CAN (KW 1281)
Superb I (3U)	Climatisation	Climatronic (KW 1281)
Superb I (3U)	Système de confort	Système de confort (KW 1281)
Superb I (3U)	Calculateur diesel	AVB 1.9 General
Superb I (3U)	Calculateur diesel	AVF 1.9 General
Superb I (3U)	Calculateur diesel	AWX 1.9 General
Superb I (3U)	Calculateur diesel	AYM 2.5 General
Superb I (3U)	Calculateur diesel	BDG 2.5 General
Superb I (3U)	Calculateur diesel	BPZ 1.9 TDI (KWP2000)
Superb I (3U)	Calculateur diesel	BSS 2.0 General
Superb I (3U)	Calculateur diesel	BSV 1.9 General
Superb I (3U)	Calculateur diesel	BWW 2.0 General
Superb I (3U)	Calculateur essence	AMX 2.8 General
Superb I (3U)	Calculateur essence	AWT 1.8 Motronic (KW 1281)
Superb I (3U)	Calculateur essence	AZM 2.8 General
Superb I (3U)	Calculateur essence	BBG 2.8 General
Superb I (3U)	Boite de vitesse automatique	Diagnose (KW 1281)
Superb I (3U)	Xénon	Xénon aim control (KW 1281)
Superb I (3U)	Antivol	Immo/Instr (KW 1281)
Superb I (3U)	Instrumentation	Instrument - Diesel (KW 1281)
Superb I (3U)	Instrumentation	Instrument - Gasoline (KW 1281)
Superb I (3U)	Radar de recul	Parking assistance (KW 1281)
Superb I (3U)	Airbag	Airbag (KW 1281)
Superb II (3T)	Autoradio	DSP (Sound system) [CAN UDS]
Superb II (3T)	Autoradio	Radio - Diagnose (CAN TP20)
Superb II (3T)	ABS	ABS with ESP (CAN TP20)
Superb II (3T)	ABS	ABS without ESP - Diagnose (CAN TP20)

Superb II (3T)	Passerelle centrale	Gateway (CAN TP20)
Superb II (3T)	Climatisation	Climatic (CAN UDS)
Superb II (3T)	Climatisation	Climatronic (CAN UDS)
Superb II (3T)	Porte	Driver door (CAN TP20)
Superb II (3T)	Porte	Passenger door (CAN TP20)
Superb II (3T)	Porte	Rear left door (CAN TP20)
Superb II (3T)	Porte	Rear right door (CAN TP20)
Superb II (3T)	Centrale électrique	Central electronics (CAN TP20)
Superb II (3T)	Calculateur diesel	BJS 1.9 General
Superb II (3T)	Calculateur diesel	BLS 1.9 General
Superb II (3T)	Calculateur diesel	BMP 2.0 General
Superb II (3T)	Calculateur diesel	BXE 1.9 General
Superb II (3T)	Calculateur diesel	CBBB 2.0 General
Superb II (3T)	Calculateur essence	BZB 1.8 TFSI (CAN TP20)
Superb II (3T)	Calculateur essence	CAXC 1.4 General
Superb II (3T)	Calculateur essence	CDAA 1.8 TFSI (CAN TP20)
Superb II (3T)	Calculateur essence	CDAB 1.8 TFSI (CAN TP20)
Superb II (3T)	Calculateur essence	CDVA 3.6 General
Superb II (3T)	Boite de vitesse automatique	Diagnose (CAN TP20)
Superb II (3T)	Xénon	Xénon aim control (CAN TP20)
Superb II (3T)	Antivol	Antivol (CAN UDS)
Superb II (3T)	Instrumentation	Instrument (CAN UDS)
Superb II (3T)	Autre	Boot lid electronics (CAN UDS)
Superb II (3T)	Autre	Multi media interface - Diagnose (CAN TP20)
Superb II (3T)	Autre	Seat module, driver - Diagnose (CAN TP20)

Superb II (3T)	Autre	Telephone - Diagnose (CAN TP20)
Superb II (3T)	Radar de recul	Parking assistance - Diagnose (CAN TP20)
Superb II (3T)	Airbag	Airbag (CAN TP20)
Superb II (3T)	Direction assistée	Direction assistée assistance (CAN TP20)
Superb II (3T)	Direction assistée	Direction assistée wheel electronics (CAN TP20)
Superb II (3T)	Attelage	Trailer module (CAN TP20)
Yeti	Autoradio	DSP (Sound system) [CAN UDS]
Yeti	Autoradio	Radio - Diagnose (CAN TP20)
Yeti	ABS	Mark 60 EC1 - ABS/ESP (CAN TP20)
Yeti	Passerelle centrale	Gateway (CAN TP20)
Yeti	Climatisation	Climatic (CAN UDS)
Yeti	Climatisation	Climatronic (CAN UDS)
Yeti	Porte	Driver door (CAN TP20)
Yeti	Porte	Passenger door (CAN TP20)
Yeti	Porte	Rear left door (CAN TP20)
Yeti	Porte	Rear right door (CAN TP20)
Yeti	Centrale électrique	Central electronics (CAN TP20)
Yeti	Calculateur diesel	CBDB 2.0 General
Yeti	Calculateur diesel	CEGA 2.0 TDI-CR (CAN TP20)
Yeti	Calculateur diesel	CFHA 2.0 General
Yeti	Calculateur diesel	CFHC 2.0 General
Yeti	Calculateur diesel	CFHF 2.0 General
Yeti	Calculateur diesel	CFJA 2.0 General
Yeti	Calculateur essence	CBZB 1.2 TFSI (CAN UDS)

Yeti	Calculateur essence	CDAА 1.8 TFSI (CAN TP20)
Yeti	Calculateur essence	CDAB 1.8 TFSI (CAN TP20)
Yeti	Xénon	Xénon aim control (CAN TP20)
Yeti	Antivol	Antivol (CAN UDS)
Yeti	Instrumentation	Instrument (CAN UDS)
Yeti	Autre	4WD electronics (CAN TP20)
Yeti	Autre	Multi media interface - Diagnose (CAN TP20)
Yeti	Autre	Seat module, driver - Diagnose (CAN TP20)
Yeti	Autre	Telephone - Diagnose (CAN TP20)
Yeti	Radar de recul	Parking assistance (CAN TP20)
Yeti	Airbag	Airbag (CAN UDS)
Yeti	Direction assistée	Direction assistée assistance (CAN TP20)
Yeti	Direction assistée	Direction assistée wheel electronics (CAN TP20)
Yeti	Attelage	Trailer module (CAN TP20)